

ABB MEASUREMENT & ANALYTICS | DATA SHEET

Magnetic pickup preamplifier overview

XSeries products



Description


The ABB Totalflow Magnetic Pickup Preamplifier/Signal Conditioner is a high performance, low power, amplifier designed for amplifying and conditioning the output signals of a magnetic pickup (such as used in liquid turbine meters). Special design considerations and on-site testing were performed with the amplifier to insure reliable operation, even under extremely noisy conditions such as: the presence of variable frequency drives, motors, or pumps.

The unit's wide power supply voltage range combined with its very low current draw make the amplifier especially suitable for use in low power applications such as solar power and remote sensing applications up to 4000 feet1 or more from its power source. The amplifier has also been designed to drive highly capacitive loads, often used for input signal debouncing and filtering. The amplifier is especially recommended when using ABB Totalflow Flow Computers or Remote Controllers. It is also excellent for driving the digital inputs of any other device having 5VDC compatible inputs.

- Specifically designed for use with turbine flow meters
- Designed for extremely noisy environments
- Very low power consumption (600 μA)
- Wide temperature operation
- · Wide power supply voltage range
- 5 Vdc output drive requires no additional pull-up resistors
- 0 to 20 KHz operation
- Capable of driving very long cables with highly capacitive loads¹

The Magnetic Pickup Preamplifier/Signal Conditioner is available in several configurations.


- Pulser Magnetic pickup amplifier electronic board only
- Mag-Pickup Amplifier/Signal Conditioner, with 15 foot cable, in flex conduit
- Mag-Pickup Amplifier/Signal Conditioner, with fittings (Customer supplies cable)
- Mag-Pickup Amplifier/Signal Conditioner, with twisted pair turbine sensor cable & 15 foot flow computer unit cable
- Mag-Pickup Amplifier/Signal Conditioner, with twisted pair turbine sensor cable & fittings, (Customer supplies flow computer unit cable)
- Mag-Pickup Amplifier/Signal Conditioner, with twisted pair turbine sensor cable, fittings & 6 foot flow computer unit cable



Mag pickup electrical characteristics

Symbol	Parameter	Condition	Min	Typical	Max	Unit
Environment	al					
T _A	Ambient operating temperature ra	nge	-40		85	Deg C
Power supply	,					
V _{supply}	Power supply voltage		7		30	Vdc
I _{supply}	Power supply voltage	I _{OUT} = 0 ma		600		μΑ
Input						
Fin	Input frequency ⁽¹⁾		0		20	KHz
V _{in_min}	Input voltage sensitivity with sinusoidal input ⁽²⁾	1 Hz		24		mVp-p ⁽³⁾
		60 Hz		24		mVp-p ⁽³⁾
		3 Hz		38		mVp-p ⁽³⁾
		10 Hz		115		mVp-p ⁽³⁾
		20 Hz		250		mVp-p ⁽³⁾
Input						
Vон	Voltage output high	I _{OUT} = -0.01 mA		5	5.05	Vdc
		I _{OUT} = -0.1 mA	4.944	5		Vdc
		I _{OUT} = -1 mA	4.892	5		Vdc
		I _{OUT} = 0.01 mA	0	0		Vdc
		Iоит = 0.1 mA		0	0.006	Vdc
		I _{OUT} = 1 mA		0	0.057	Vdc

Wiring example



- enclosure front cover.
- 1. The preamp is DC coupled and can sense differential signals down to 0 Hz. However, inductive pickups do not generate signals this low since they are inherently an AC type signal generator. For reference, a small 1" Halliburton turbine meter Part No. 458-85228, with Mag Sensor EC 3030AN is normally rated for operating with a minimum flow rate of 5 GPM (Gallons Per Minute), which would generate a Minimum Pulse Output Frequency of 79 Hz.
- 2. The input of the preamp is a fully differential input designed for connection directly to floating inductive sensors such as used on turbine meters. It is not designed for single ended input applications. Attempting to directly drive the preamp inputs with a single ended device (such as a signal generator) will result in improper operation. For field test procedures, please contact ABB Totalflow for test configuration details.
- 3. Millivolts peak to peak.



ABB Inc.

Measurement & Analytics

Quotes: totalflow.inquiry@us.abb.com
Orders: totalflow.order@us.abb.com
Training: totalflow.training@us.abb.com
Support: totalflowsupport@us.abb.com

+1 800 442 3097 (opt. 2)

Main Office

7051 Industrial Boulevard Bartlesville, OK 74006 Ph: +1 918 338 4888

www.abb.com/upstream

California Office

4300 Stine Road Suite 405-407 Bakersfield, CA 93313 Ph: +1 661 833 2030

Kansas Office

2705 Centennial Boulevard Liberal, KS 67901 Ph: +1 620 626 4350

Texas Office - Odessa

8007 East Business 20 Odessa, TX 79765 Ph: +1 432 272 1173

Texas Office - Houston

3700 West Sam Houston Parkway South, Suite 600 Houston, TX 77042 Ph: +1 713 587 8000

Texas Office - Pleasanton

150 Eagle Ford Road Pleasanton, TX 78064 Ph: +1 830 569 8062

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB.

© Copyright 2019 ABB. All rights reserved.